

## Using Mlink Into Frad with Digi

Make an 8-wire connector with the following pin-out:

Wire	Pin
1	6
2	4
3	not used
4	2
5	3
6	7
7	5
8	20

**Note:** The Port **MUST** be **DISABLED**

Use an 8 wire head-to-head cable to connect to the Supervisory Port of the Frad. Dial in to the customers system, hit **ctrl-],** choose **[c]** and **ENTER**. Choose **[s]** and **ENTER**, choose **[e]** and **ENTER**, then change the escape sequence to **ctrl b**, or whatever you can remember. Hit **ENTER** until you get back to a **Pound Sign**. Type **mlink** and **y** to configure, hit **[c]** for communications, & hit **[c]** for port type in tty?? (whatever port the Frad is connected to on the digi.) Hit **ENTER** until the Frad screen comes up. Then you can go to work.