

Telephone (Biscuit) Jack Wiring for Digi/Ethernet

If you are using the recommended 8-wire category wire for your wiring, then the following sequence will be utilized:

With your Jack facing down (or towards your feet) the sequence is as follows:
(Starting in your upper left hand corner going down, then going up to your right Corner going down).

0-1	5-0
0-2	6-0
0-3	7-0
0-4	8-0

The Zero's represent Screw head Placement 1 thru 8.

1=Blue
2=Green
3=Orange
4=Brown
5=White/Blue
6=White/Green
7=White/Orange
8=White/Brown

Note: If you have a different MFG. For your telephone jacks, the sequence may differ. Please refer to support for further information

Grn 01/19/02