

### Pinout for Null Modem Serial Cable

Note: This is the type of cable that is needed for the slaving of a Printer off of the back of a TCS.

- a. Cut and strip back the insulation shielding your Cat 5 strands (You should end up with Eight multi-colored wires.
  1. Green-Green
  2. Red-Orange
  3. Orange-Red
  4. Blue-Yellow
  5. Yellow-Blue
  6. Purple-Grey
  7. Gray-Purple
  8. Black-Black
  9. Brown-Brown
  10. Shielded Cable-Shielded Cable