

Making a Dos Boot disk that will support IDE cd ROMs

Insert a disk in the A drive. Make sure the disk is not written protected. From the Dos prompt type:

1. format a:
2. C:\
3. sys a:
4. copy c:\windows\command\fdisk.exe a:\
5. copy c:\windows\command\format.com a:\
6. copy c:\windows\command\sys.com a:\
7. copy c:\windows\command\mscdex.exe a:\
8. copy c:\windows\command\atapicd.sys a:\
9. copy con a:\config.sys
10. device=atapicd.sys /d:cdrom001
11. (ctrl +Z) (enter)
12. copy con a:\autoexec.bat
13. mscdex.exe /d:cdrom001
14. (ctrl+Z) (enter)

grn 01/19/02