

Add the 9 To the Modem Number

From the prompt type # cd /abcconfigs

then hit the **enter** key

From the prompt type # nte modempfx

then hit the **enter** key

A Blue screen will appear that should have a period, followed by a space (which is equal tab spacings) a "**t9**", followed by a comma, then a minus sign followed by a **ampersign**.

Example (1 Tab) **t9,-&**

When finished, hit the F-2 Key for the Menu

Then hit the X Key, to save and exit.

Answer "Yes" to save all changes.