

To Flash the Firmware on a Sony Tape Drive

- Shutdown the machine using the `shutdown -g0 -y` command type it the shutdown at a # sign
- Remove the cover
- Pull the wide flat cable out of the tape drive
- Leave the small power cable in the tape drive and turn on the machine
- Put the Firmware tape in as soon as you power up
- When the lights stop flashing on the tape push the eject button on the tape drive
- Shutdown the computer and reattach the wide cable
- Put the cover back on and turn on the computer
- After you log in try to do a backup
- Please return the tape to Advantage Business Systems