

Using Mlink into Frad with Digi

Make an 8-wire connector with the following pin-out:

Wire	Pin
1	6
2	4
3	not used
4	2
5	3
6	7
7	5
8	20

Note the port must be disable

Use an 8 wire head-to-head connected to the supervisory port of the frad. Dial into customers system hit ctrl-] choose [c] and enter choose [s] and enter [e] and enter, change the escape sequence to ctrl b or what ever you can remember. Hit enter till you get back to the pound sign. Type mlink and y to configure, [c] for communications [c] for port type in tty???? Whatever port the frad is connected to the digi, hit enter till the frad screen comes up. Then you can go to work