



To reset to factory defaults:

- 1.) with a pointed object, press the reset button located on the front of the AP.
- 2.) count 10 seconds, then hold down the reload button with the same pointed object while the AP boots.
- 3.) when it is finished booting the power light will be orange and the ethernet light will be the only one blinking.
- 4.) on the connected pc click Start > Programs > ORiNOCO > AP Manager.
- 5.) in the AP Manager software, click Access Point > Upload Software...
- 6.) click wpnt370.bin, then click Open.
- 7.) click No.
- 8.) click OK.