


IEE ScanVue Kiosk Scanner / Price Checker For 12 Digit Barcodes


Recall Defaults

999998




*Enable RS-232

415554



When this option is enabled, the scanner
will work with RS-232 +/-12V serial
output.


999999



Enter/Exit
Configuration Mode


*Enable UPC/EAN

100116




*Enable UPC-A

100216




*Enable UPC-E

100210




*Transmit UPC-A
Check Digit

116617



Transmit UPC-E
Check Digit

107516




*Transmit UPC-A
Number System

107511




*Disable UPCPrefix ID

116607



Do not send prefix ID Characters with
UPC/EAN codes.

999999



Enter/Exit
Configuration Mode