

How to Connect a Percon Power Wedge 10 to a Mercury RF Unit

1. Connect the 9 pin serial cable supplied with the Mercury RF unit to the Mercury set up for the terminal.
2. Connect a 9 pin to 25 pin adapter (25 pin male, 9 pin female) to the 9 pin serial cable from the Mercury RF unit.
3. Get the Y adapter 25 pin serial cable supplied with the Percon Power Wedge 10.
4. Plug the plug labeled Percon to the back of the Percon Power Wedge 10 where it says HOST INTERFACE.
5. Connect the 25 pin serial cable labeled computer that runs from the Percon Power wedge 10 to the 25 pin side of the 9 pin to 25 pin adapter.
6. Connect the 25 pin serial cable labeled terminal that runs from the Percon Power Wedge 10 to the serial 1 port on the computer.
7. Plug the Mercury RF unit and the Percon Power Wedge 10 into the power outlet.