

PSC QUICK SCAN W/KBD WEDGE



This scanner is designed to connect to any ps/2 style keyboard and keyboard port. It can be connected to an AT style keyboard or keyboard port by means of an adapter. It can be used with the following terminals:

Serial Spot Line

Ethernet Spotline


Thin Client

Bottom of scanner →




Plug the 8 wire connector into the port on the bottom of the scanner. Make sure you hear a snap when you plug it in.

Plug the cable coming from the keyboard into the female port.



Plug the male cable into the keyboard port on the back of the terminal. The keyboard port is generally the port on bottom or on the left.



PSC QUICK SCAN W/KBD WEDGE

This Barcode will set the wedge back to it's factory default settings

ZA



This barcode will enable keyboard wedge mode

CE



This Barcode sets the wedge to communicate through the keyboard

CF



This barcode will prevent the scanner from reading the first digit in a 12 digit barcode

QD



This barcode will prevent the scanner from reading the last digit in a 12 digit barcode.

QF




This Barcode Appends a carriage return to the barcode output.

MC



PSC QUICK SCAN W/KBD WEDGE

This section appends two carriage returns to the output. This will cause the cursor to move to the next line when you enter a barcode from point of sale. If you want to stop on the quantity field do not scan this section.



LB	
0	
D	
0	
D	
0	
0	
0	
0	

PSC QUICK SCAN W/KBD WEDGE

This section Enables 5 of 2 barcodes and formats them for use with the advantage software. They have no effect on UPC barcodes.

