

SYMBOL LS5700/LS5800

WITH STI80 SYNAPSE KEYBOARD WEDGE

SCAN SHEET





NO PREAMBLE
(<DATA>)



DO NOT TRANSMIT
UPC-A CHECK DIGIT




PRIMARY SCANNER PORT



SEND ALL DATA THAT REMAINS

**SCAN THE SEND ENTER KEY
ONCE FOR ONE CR
OR TWICE FOR TWO CR**



SEND ENTER KEY



SAVE RULE