


# SYMBOL LS9100

## WITH STI80 SYNAPSE KEYBOARD WEDGE

### SCAN SHEET



# **SYMBOL LS9100**

**WITH STI80 SYNAPSE KEYBOARD WEDGE**

**SCAN SHEET**





ENABLE LS 9100 COMMUNICATION



IBM PC/AT  
IBM PS/2-50, 55SX, 60, 70, 80  
(DEFAULT)



NO PREAMBLE  
(<DATA>)



DO NOT TRANSMIT  
UPC-A CHECK DIGIT




PRIMARY SCANNER PORT



SEND ALL DATA THAT REMAINS

**SCAN THE SEND ENTER KEY**  
ONCE TO STOP ON THE QUANTITY FIELD  
OR TWICE TO STOP ON THE NEXT LINE IN  
POINT OF SALE



**SEND ENTER KEY**



**SAVE RULE**

**SCAN THIS OPTION ONLY IF YOU  
HAVE A TRIAD VERSION LS9100**



**APPLICATIONS ITEM 2  
DISABLE**