

/home/dave/ingenico.txt

Ingenico eN-Touch 1000 Baud Rate Change Procedure

1. Connect the eN-Touch 1000 to the PC's serial port
2. Connect the power supply to the serial cable
3. From any screen, access the menu selection screen by doing:
 - A.touch the top left corner once
 - B.touch the bottom left corner once
 - C.touch the bottom right corner once
 - D.touch the top right once
 - E.touch the top left corner once
4. Select "SUPERVISOR MENU"
5. At the "ENTER PASSWORD" prompt, type "263", and touch "ENTER"
6. touch the "NO" button to change the prompt to "FILESYSTEM"
7. touch the "ENTER" button to select "FILESYSTEM"
8. touch the "NO" button to change the prompt to "WRITE"
9. touch the "ENTER" to select "WRITE"
10. when prompted for "APP#" type in "15" and touch the "ENTER"
11. when prompted for "FILE#" type in "32769" and touch the "ENTER"
12. when prompted for "RECORD#" type in "10" and touch the "ENTER"
13. when prompted for "CLASS#" type in "1" and touch the "ENTER"
14. when prompted for "DATA" type in "9600" and touch the "ENTER"
15. when prompted touch anykey on the pad.
16. at the "WRITE" prompt power off the device
17. power the device back on and watch for the baud rate setting to verify the changes have taken effect.

NOTE: if "AUTODETECT" feature starts on boot then use this procedure to turn it off

1. From any screen, access the menu selection screen by doing:
 - A.touch the top left corner once
 - B.touch the bottom left corner once
 - C.touch the bottom right corner once
 - D.touch the top right once
 - E.touch the top left corner once
2. Select "SUPERVISOR MENU"
3. At the "ENTER PASSWORD" prompt, type "263", and touch "ENTER"
4. touch the "NO" button to change the prompt to "FILESYSTEM"
5. touch the "ENTER" button to select "FILESYSTEM"
6. touch the "NO" button to change the prompt to "WRITE"
7. touch the "ENTER" to select "WRITE"
8. when prompted for "APP#" type in "15" and touch the "ENTER"
9. when prompted for "FILE#" type in "32769" and touch the "ENTER"
10. when prompted for "RECORD#" type in "2" and touch the "ENTER"
11. when prompted for "CLASS#" type in "1" and touch the "ENTER"
12. when prompted for "DATA" type in "0" and touch the "ENTER"
13. when prompted touch anykey on the pad.
14. at the "WRITE" prompt power off the device
15. power the device back on and watch for the "AUTODETECT" setting to verify the changes have taken effect.