

HP 4050 with Duplex Setup

Push **Menu** until you see Paper Handling Menu
Push **Item** until you see Duplex
Push **Value 1** time until on
Push **Select** to Set This Value
Push **Go** to go to Ready Mode

While using Duplex (Printing on both sides of the paper) you will encounter one problem on a single page print. If a print job has a single page at the end you have to press the **Go** button to get the last page.

When Duplex Mode is off this does not happen.