

# Configuring the IP Address on the Dell 2330dn printer

1. Press the Menu Button and press → until you come to Network/Ports and press the “Check Mark”.
2. Press the → until you get Network Menu and press the “Check Mark”.
3. Press the → until you get Network Setup and press the “Check Mark”.
4. Press the → until TCP/IP shows up and press the “Check Mark”.
5. Use the → to get to Activate and press the “Check Mark” to make sure that it has been activated.
6. Use the → to go to IP Address and press the “Check Mark”.
7. You will use the ← and → to change the numbers to the proper IP. Press the “Check Mark” to go to the next set of numbers and complete.
8. Press the → until you get Subnet Mask and press the “Check Mark”. Set the Subnet Mask to 255.255.255.0.
9. Press the → until you get Gateway and press the “Check Mark”. Enter the proper gateway and press the “Check Mark” to get the printer to display that it is saving the settings.
10. Press the Back Button Until you get to Admin Menu.
11. Press the → and go to Setup & press “Check Mark”.
12. Press the → to go to PCL Emul Menu and press the “Check Mark”.
13. Press the → to go to PCL Emulation Settings and press the “Check Mark”.
14. Press the → to go to Auto CR after LF and press the “Check Mark”.
15. Press the → to change it to on and press the check mark.
16. Hit back until the printer is online.