

Configuring the IP Address on the Dell 5330dn printer

1. Press the Menu Button and press ↓ until you come to Network I/O Ports and press the “Check Mark”.
2. Press the ↓ until TCP/IP (IPv4) shows up and press the “Check Mark”.
3. Use the ↓ to get to IPv4 Activate and press the “Check Mark” to make sure that it has been activated.
4. Use the ↓ to go to Set IP Address and press the “Check Mark”.
5. Choose Manual and press the “Check Mark”.
6. You will use the ← and → to go to each individual number and use the ↑ and ↓ to change each numbers value from 0-9.
7. After you have entered the desired values press the “Check Mark” and it will go to the Subnet Mask screen automatically.
8. Set the Subnet Mask to 255.255.255.0 and press “Check Mark” again and it will go to the Gateway entry. Enter the proper gateway and press the “Check Mark” to get the printer to display that it is saving the settings.
9. Press the Menu Button and go to Settings & press the “Check Mark”.
10. Use the ↓ and go to Setup & press “Check Mark”.
11. Use the ↓ to go to Auto CR: and press the “Check Mark”.
12. Set the value to CR+LF and press the “Check Mark”.