

# Configuring the Dell 5210 Laser Printer

1. Press the Menu Button on Printer you should see ">Paper Menu"
2. Press the Down Arrow until you see "Network/Ports" and press the "Check Mark" button
3. You should see ">TCP/IP" press the "Check Mark" button.
4. Press the "Check Mark" button you should see ">Activate"
5. Press the "Check Mark" Choose "On" and Press the "Check Mark" Again
6. The Printer will display "Submitting Selection" it will then return to the menu.
7. Press the Down Arrow until you see "Address" and press the "Check Mark" button
8. Use the up and down arrow keys to enter your IP address and the left and right arrow keys to go between sets of numbers.
9. When you have entered the address press the "Check Mark" Button. The Printer will display "Submitting Selection". It will then return to the menu.
10. Press the Down arrow you should see "Netmask"
11. Press the "Check Mark" button and use the up and down keys to enter your Netmask Address and the left and right arrow to go between sets of numbers.  
Note: your netmask will usually be "255.255.255.0"
12. When you have entered the address press the "Check Mark" the Printer will display "Submitting Selection" it will then return to the menu.
13. Press the Down arrow you should see "Gateway" Press the "Check Mark"
14. Use the up and down arrow keys to enter your Gateway address and left and right arrow keys to go between sets of numbers.
15. When you have entered the address press the "Check Mark" the Printer will display "Submitting Selection" it will then return to the menu.
16. Press the Down arrow you should see "Enable DHCP", Press the "Check Mark"
17. Choose "OFF" and Press the "Check Mark" Again
18. The Printer will display "Submitting Selection" it will then return to the menu.
19. Press the Down arrow you should see "Enable Auto IP", press "Check Mark"
20. Choose "OFF" and Press the "Check Mark" Again. The Printer will display "Submitting Selection" it will then return to the menu.
21. Press the Back button until you see "Network/Ports" then
22. Press the Up arrow until you see "Settings" and press the "Check Mark" and you should see "Setup Menu"
23. Press the Down arrow until you see "PCL Emul. Menu" and press the "Check Mark"
24. Press the Down arrow until you see ">PCL Emulation Settin..." and press the "Check Mark"
25. Press the Down arrow until you see "Auto CR after LF" and press the "Check Mark"
26. Choose "ON" and Press the "Check Mark" Again. The Printer will display "Submitting Selection" it will then return to the menu. Press the Back button until you see ready