


Adding an Oki Printer to the Serial Port of a Thin Client

When adding an Oki Printer to a thin client, you will need to go into sysut, choose printer, then choose software printer maintenance. In Software printer maintenance press insert to add a new printer. Enter R next to [L]ocal/[R]emote/[T]ransparent. Next to printer type, type in oki321f. In the device file or spool command field type | tcsprint tcsname ser > /dev/null 2>&1 where tcsname is the name of the tcs. For example, if this printer is on tcs101 the spool command would be | tcsprint tcs101 ser > /dev/null 2>&1

```
Printer Id code.....: lp01
Description.....: invoice printer
Location.....: front
[L]ocal/[R]emote/[T]ransparent: R
Printer type ([F?] for query): oki321f
Forms class.....: plnpaper
Device, file or |SpoolCommand: | tcsprint tcs101 ser >/dev/null 2>&1
Command to execute before open:
Command to execute after close:
```



Connect the Serial port on the thin client to the serial card on the printer with a DB9 female to DB25 male cable. You must have a serial card in the printer in order to connect through the serial port.