

# OKIDATA 320T/321T PRINTER SETUP

First, make sure you have power to your printer. Make sure the paper is properly loaded in the printer. Then pull the front cover forward so you can clearly see the print line. Now return your printer to factory default settings by turning your printer off, holding down the **SEL + LF** keys while turning your printer back on.

Now enter the Configuration Mode. Do so by pressing the **SELECT**. Then press the **SHIFT & SELECT** buttons. The Menu Light should come on.

NOTE: (2x) Means the number of times you press that button.

- GROUP** (1x) This should put you in the **PRINTER CONTROL** group
- SET** (1x) To set your emulation to **Epson FX**
- GROUP** (3x) This should take you to the **REAR FEED** group .
- ITEM** (1x) **Form Tear-Off**
- SET** (1x) **500 ms (or On)**
- GROUP** (1x) This will take you to the **BOTTOM FEED** group.
- ITEM** (1x) This puts you in the **Form-Tear-Off** item group.
- SET** (1x) To set this option to **500ms**
- GROUP** (2x) This will put you in the **SET-UP** group
- SET** (1x) To set your graphics option to **BI-DIRECTIONAL**. (**STOP! If you are connecting to a Parallel Port, Skip the next five settings**)
- GROUP** (2x) This will put you in the last group, **SERIAL I/F**. (DO NOT USE THIS SETTING IF YOU ARE CONNECTING VIA THE PARALLEL PORT)
- ITEM** (4x) This will take you to the **Busy Line** option. (DO NOT USE THIS SETTING IF YOU ARE CONNECTING VIA THE PARALLEL PORT)
- SET** (2x) To change this option to **DTR**. (DO NOT USE THIS SETTING IF YOU ARE CONNECTING VIA THE PARALLEL PORT)
- ITEM** (2x) This will take you to the **DSR Signal** item group. (DO NOT USE THIS SETTING IF YOU ARE CONNECTING VIA THE PARALLEL PORT)
- SET** (1x) To change this option to **invalid**. (DO NOT USE THIS SETTING IF YOU ARE CONNECTING VIA THE PARALLEL PORT)

If you are connecting this printer utilizing the Parallel Port, finish the setup by utilizing the following information...

After going through this procedure hold **SHIFT/SEL** to save your settings and return the printer online. If you need to add a serial interface card, simply turn the power off to the printer. Then pry out the plastic cover next to the parallel interface. Then slide the serial interface card into the slot, seating firmly. NOTE: You may **ONLY** print using "one" interface connection at a time. This printer is command menu configured. Good Luck

If you need to print a copy of the configurations press **SHIFT** and **MENU**. Then press **PRINT**.