

Resetting the Tear Off on Okidata Printer

Holding down the Park and Quiet Button, set the form to top of Tear off.