

CONFIGURATION AND PINOUT FOR THE OL810E LASER PRINTER

To rest this printer to factory default.

1. Turn off printer.
2. While holding "Menu1-Menu2" and "Reset" turn the printer back on.

You should now be reset to config the printer or the ABCS software.

Lines per page needs to be set to 66. To do this:

1. Press "Online" to take the printer offline.
2. Press "Menu 1-2 (10) times to page layout 2.
3. Press "Enter".
4. Press "Menu 1-2 to go to "Lines per Page."
5. Press Right Arrow six (6) times to change lines to 66.
6. Press "Enter".
7. Press "Menu 1-2.
8. Press "Online."