

Programming the OL1200 Printer

The following steps are for programming the Okidata OL1200 printer for interface with Advantage System.

- Press On line to take printer off line
- Press Paper Size/Print Menu and hold for 2 seconds for print out
- The right hand column shows you current selections

Below are the recommended changes for factory default

Level 1

Category	Option
Paper Size	Executive
Symbol Set	PC-8
Page Layout	80 Column
Lines Per Inch	66 Lines

Level 2

Darkness Control	+2
Power saving	8 min or Disabled

To Program Menu 1

- Press Menu1/Menu2 to change categories
- Press Enter to select the category you want to work in
- Press > (right arrow) to see option in the category
- Press Online to exit and save

To Program Menu 2

- Press Online to take printer off line
- Press Menu1/Menu2 and Hold for 2 seconds
- Press Menu1/Menu2 to change categories
- Press Enter to select the category you want to work in
- Press > (right arrow) to see options in the category
- Press enter on the option you want, it will be marked with an *
- Press Online to exit and save