

Config & Initialize Megaraid

Press **Control** and the letter **M** as it appears on the screen.

Arrow to **objects** and press enter.

Arrow to **adapter** and press enter.

Arrow down to **disk spin time** and press enter.

Select **2 every 6 seconds** and press enter.

Select yes.

Press escape.

Arrow down to **cache flush timing** and press enter.

Arrow down to **every 10 seconds** and press enter.

Select yes.

Arrow down to **ultra scsi** and press enter.

Select **disable** and press enter.

Press escape.

Press escape.

Select **configure** and press enter.

Select **easy configuration** and press enter.

Press enter to see if there is more to configure.

Press space bar to make all online, then enter.

Arrow down to **advanced menu** and press enter.

Arrow down to **write policy** and press enter.

Select **wr back** and press enter.

Arrow down to **read policy** and press enter.

Select **adaptive** and press enter. (always accept)

Select escape and press enter to **easy configuration**. (Space bar makes online, arrow back to drive)

Repeat Select yes and press enter to save configuration.

Escape to management menu.

Format if time permits.

Arrow down to initialization.

F2 to select all.

Space bar to select and deselect.

F10 to initialize (low level format).

Press any key to continue.

Escape and exit for reboot.

Allow to arrive at boot prompt (boot:)

Type **link** at the prompt and press enter.

Type **amird** and press enter.

Put amird disk in drive and press enter.

Put boot disk in drive and press enter.

Press enter.

Normal load from here on out.

Never relink kernel.