

# RAID SETUP

After Megaraid is through initializing press Control M

Go to Objects [enter]

Adapter [enter]

Disk spinup [enter]

2 disks every 6 seconds [ESC]

Cache Flash Time [enter]

Every 10 seconds [ESC]

Ultra SCSI = Disabled [ESC]

ESC (2) times

Configure [enter]

Easy configuration [enter]

Example:

3 Drives = Raid 5

2 Drives = Raid 3

1 Drives = Raid 0

Press spacebar to make drives online then [enter]

Advance [enter]

Write Policy = Wrbck use enter to change

Read Policy = Adaptive

ESC Accept [enter] so the same for all logical drives

ESC

Save Configuration Yes [ESC]

Initialize - Save - Yes

Loading SCO 504

At the boot type link [enter]

What do want to link = amird [enter]

Screen will prompt you for amird disk

The rest of the installation is same as regular 504