

Customer Changes Baud Rate on Console, Now cannot login and or operate console

The problem with this scenerio, is that the customer probably corrupted the ininitab file. If so, then you will need to go in and edit each console line (RE: 01,02,03,04....etc) with the proper sh_m emulation at the end of the line. If it says abcsm, even though it may be set to a 9600 Baud rate