

# Configuring the Portservers

Turn the portserver on

As soon as the portserver lights up, press both the green arrow keys to reset to the factory defaults.

With a terminal set up on the port 1 of the portserver set up as vt100,8,n,1,9600baud

Hit **enter** and you should see a login

Login as root with a passwd of dbps

You should see:>

Type **set config ip=(your IP Address)**

If you have a router type **set config router=(IP Address)**

Type **set ports range=2-16 dev=prn**

Turn the portserver **off** and back **on**

You should now be able to use sysut just like and other digi product