

PORTSERVER II

You will need the following:

- Your portserver(s)
- A copy of the REALPORT 3.2 driver
- A list of your ethernet addresses and router addresses

Installing Realport:

Place the realport driver disk in the disk drive

Log in as root

From the # sign type **custom**

Arrow over to **software** and hit **enter**

Arrow down to **install new** and hit **enter**

Arrow down to **from floppy drive 0** and hit **enter**

Choose the **realport driver**, hit **tab**, highlight **install**, and hit **enter**

Hit **enter** to accept license

Type **Y** to accept tty's

If you want the software to assign tty id's hit **y** - if not, choose **n**

Tell the software **how many** portservers to install

Tell the software the **ip's** of the portservers

It will show you the setup of the portserver - if correct, choose **y**

It will ask if you want to update /dev/tty - answer **y**

The kernel will relink and then ask you if you want to accept the new config - type **y**

It will ask if you want to rebuild the termdevs-choose **y**

Hit **enter** to continue

Hit **enter** for ok

Arrow over to hosts and hit **enter**

Choose **exit** and hit **enter**

Reboot your system



PortServer II



PortServer TS 8



PortServer TS 16