

## Adding an Ethernet Card



1. Shut down your machine and slide the new ethernet card into one of the PCI slots - usually it fits right underneath the video card. Make sure the card is firmly in place.
2. Boot your machine back up.
3. Once at a pound sign (#), type **netconfig** [enter]
4. **Hardware** [enter]
5. Choose **Add new LAN Adapter** [enter]
6. **Arrow** down to the card you are installing [enter]
7. Network Driver Configuration, **tab** down to **Ok** [enter]
8. **Arrow** down to **SCO TCP/IP** [enter]
9. **Tab** down to **add** [enter]
10. **Tab** down to **IP address**, type **200.10.10.100** (or whatever IP address you would like)
11. **Tab** down to **Ok** [enter]
12. Now it should show you what was just installed, **Ok** [enter]
13. **Hardware** [enter]
14. **Arrow** down to **Exit** [enter]
15. Relink the kernal, type (y) [enter]
16. Boot by default, type (y) [enter]
17. Rebuild environment, type (y) [enter]
18. Hit [enter] when prompted
19. Now reboot the system for the card to initialize.