

Programming the Printronics Proline Serial 5

1. Raise the top cover
2. Press right arrow one. Should take you to emulation
3. Press down arrow three times. Should take you to printer protocol
4. Change Epson Fx with the right or left arrows.
5. Press the up & down arrow at the same time to unlock it, then select it by pressing the enter key.
6. Lock it back with the up and down arrows at the same time.
7. Go back up with the arrow key three times to emulation. Then right arrow twice to host interface.
8. Down arrow once the host interface to serial with the right or left arrow.
9. Unlock it by pressing the up and down arrows at the same time then select it by pressing enter and lock it back by pressing up and down arrows at the same time again.
10. Put printer online